



Model No.TR001G CORDLESS REBAR TYING TOOL



Model No.TR001G CORDLESS REBAR TYING TOOL



Model No.TR001G CORDLESS REBAR TYING TOOL

Item No.	Parts No.	Description	Interchangability	Q'ty	New/Old	Note1	Note2
001	262054-7	Urethane ring 3		1		INEL URETAN 3	
002	256A96-7	GROOVED PIN 4B		1			
003	268238-5	Pin 5		1		PIN 5	
004	212009-2	Needle bearing 509		1		RULMENT AXIAL 509	
005	1412D2-8	MAGAGINE COVER COMPLETE		1			
006	232924-4	COMPRESSION SPRING 11		1			
007	312H72-4	REEL BEARING		1			
008	941051-3	Flat washer 4		1		SAIBA PLATA 4	
009	266007-8	Binding head tapping screw 3X10		1		HOLDSURUB 3X10	
010	233388-5	Compression spring 5		1		ARC COMPRESIE 5	
011	347D47-0	GUIDE PLATE		1			
012	266007-8	Binding head tapping screw 3X10		1		HOLDSURUB 3X10	
013	4131T9-3	MAGAZINE COVER LOCK		1			
014	262054-7	Urethane ring 3		1		INEL URETAN 3	
015	256A93-3	GROOVED PIN 4A		1			
016	266404-8	Binding head tapping screw 3X14		2		SURUB	
017	312H73-2	REEL BASE		1			
018	1410Y0-7	MAGNET HOLDER D COMPLETE		1			
019	232921-0	COMPRESSION SPRING 4C		1			
020	4131U3-2	PLATE COVER		1			
021	266404-8	Binding head tapping screw 3X14		2		SURUB	
022	268136-3	Pin 4		1			
023	232925-2	TORSION SPRING 4A		1			
024	347D33-1	SIDE PLATE		1			
025	911008-8	Pan head screw M3X8 WR		2		PAN HEAD SCREW M3X8	
026	1831M0-3	Housing set		1			
C10	263005-3	Rubber pin 6		2		DOP CAUCIUC 6	
C20	252126-6	Hex. lock nut M4-7		2		PIULITA BLOCARE HEX M4-7	
C30	8091F3-7	Caution label A		1			
C40	8091F5-3	Caution label B		1			
C50	8091F1-1	Indication label		1			
026		INC. 61					
027	256A89-4	SHOULDER PIN 4C		1			
028	347D30-7	STOPPER BASE		1			
029	232916-3	TORSION SPRING 4B		1			
030	313610-7	STOPPER		1			
031	911008-8	Pan head screw M3X8 WR		1		PAN HEAD SCREW M3X8	
032	1410X5-0	MAGNET HOLDER C COMPLETE		1			
033	911008-8	Pan head screw M3X8 WR		1		PAN HEAD SCREW M3X8	
034	232922-8	COMPRESSION SPRING 4B		1			
035	1410Y1-5	MAGNET HOLDER A COMPLETE		1			
036	4131U6-6	SLIDE PLATE COVER		1			

037	266007-8	Binding head tapping screw 3X10		1		HOLDSURUB 3X10	
038	347D32-3	SLIDE PLATE		1			
039	347D38-1	SLIDE PLATE GUIDE		1			
040	266007-8	Binding head tapping screw 3X10		1		HOLDSURUB 3X10	
041	458219-9	Trigger lock		1		OPRITOR DECLANSARE	
042	234037-7	Compression spring 5		1		ARC COMPRESIE 5	
043	458220-4	Trigger		1		DECLANSATOR	
044	632W63-2	SWITCH UNIT		1			
045	1411B8-6	CONTROLLER COMPLETE		1			
046	632P65-6	Terminal unit		1		UNITATE TERMINAL	
047	911008-8	Pan head screw M3X8 WR		1		PAN HEAD SCREW M3X8	
048	266007-8	Binding head tapping screw 3X10		1		HOLDSURUB 3X10	
049	232922-8	COMPRESSION SPRING 4B		1			
050	1410Y1-5	MAGNET HOLDER A COMPLETE		1			
051	4131U6-6	SLIDE PLATE COVER		1			
052	347D32-3	SLIDE PLATE		1			
053	266007-8	Binding head tapping screw 3X10		1		HOLDSURUB 3X10	
054	347D38-1	SLIDE PLATE GUIDE		1			
055	313610-7	STOPPER		1			
056	347D30-7	STOPPER BASE		1			
057	232916-3	TORSION SPRING 4B		1			
058	256A89-4	SHOULDER PIN 4C		1			
059	266130-9	Binding head tapping screw 3X16		17		HOLDSURUB PT 3X16	
060	911008-8	Pan head screw M3X8 WR		2		PAN HEAD SCREW M3X8	
061	1831M0-3	Housing set		1			
C10	263005-3	Rubber pin 6		2		DOP CAUCIUC 6	
C20	252126-6	Hex. lock nut M4-7		2		PIULITA BLOCARE HEX M4-7	
C30	8091F3-7	Caution label A		1			
C40	8091F5-3	Caution label B		1			
C50	8091F1-1	Indication label		1			
061		INC. 26					
062	266404-8	Binding head tapping screw 3X14		2		SURUB	
063	4131U3-2	PLATE COVER		1			
064	347D33-1	SIDE PLATE		1			
065	268136-3	Pin 4		1			
066	232925-2	TORSION SPRING 4A		1			
067	266007-8	Binding head tapping screw 3X10		2		HOLDSURUB 3X10	
068	266490-9	Pan head tapping screw 2X6		3		HOLDSURUB	
069	652069-6	Flat head screw M3X6		3		SURUB "+" M3X6 (SP+SG)	
070	629D10-8	STATOR		1			
071	619896-4	ROTOR		1			
072	122K70-6	TWIST ASSEMBLY		1			
073	266490-9	Pan head tapping screw 2X6		3		HOLDSURUB	

074	629D11-6	STATOR		1		
075	652069-6	Flat head screw M3X6		3		SURUB "+" M3X6 (SP+ SG)
076	619897-2	ROTOR		1		
077	256A08-0	PIN 5		1		
078	122K54-4	CURL GUIDE ASSEMBLY		1		
079	1411G5-7	CUTTER COMPLETE		1		
080	232923-6	COMPRESSION SPRING 4D		1		
081	347D29-2	CUTTER BASE		1		
082	313613-1	WIRE BENDER		1		
083	313606-8	CUTTER GUIDE		1		
084	265634-8	Hex. socket head bolt M3X8		4		SURUB INBUS M3X8
085	313608-4	WIRE GUIDE B		1		
086	347D34-9	CURL GUIDE C		1		
087	265634-8	Hex. socket head bolt M3X8		1		SURUB INBUS M3X8
088	327E72-3	SHOULDER SLEEVE 4B		1		
089	122K71-4	RELEASE LEVER ASSEMBLY		1		
090	253623-5	FLAT WASHER 9		1		
091	327E71-5	SHOULDER SLEEVE 4A		1		
092	922147-9	Hex. socket head bolt M4X25		1		HOLDSURUB
093	122K72-2	FEED GEAR BASE ASSEMBLY		1		
094	232919-7	COMPRESSION SPRING 6		1		
095	253632-4	FLAT WASHER 7		2		
096	137328-4	Spur gear 21 assembly		2		
097	253077-6	Flat washer 6		2		SAIBA PLATA 6
098	961011-9	Stop ring (EXT) E-4		2		SAIBA DE SIGURANT A E-4
099	313603-4	WIRE GUIDE A		1		
100	266080-8	Hex. socket head bolt M3X12		2		SURUB INBUS M3X12
101	4131T8-5	GEAR COVER		1		
102	265E18-0	H.S.H.BOLT M3X17		1		
103	8151G5-0	Name plate TR001G		1		
104	8151G9-2	Serial No. label TR001G		1		
A01	194381-3	Oil vessel set		1		
A02	266622-8	Truss head screw M4X12		1		
A03	347D31-5	HOOK		1		
A04	783208-8	Hex. wrench 2.5		1		
A05	821552-6	Connector plastic case (type 4)		1		
C10	453974-8	Latch		4		
A06	836433-1	Inner tray		1		
F01	1915N0-0	Tie wire set		1		
F02	1915N1-8	Galvanized tie wire set		1		
F03	1915N2-6	Poly coated tie wire set		1		
F04	1915N3-4	Stainless steel tie wire set		1		
F05	1915N6-8	EXTENSION HANDLE SET		1		